

Lock Operation Guide

ent
COMPOSITE



Standard Lever Handle Operation

With a lever handle on your Entrance Composite Door supplied with our 'Standard' hardware type, you are provided with a German manufactured multipoint lock from Winkhaus.

It features 2 compression hooks and a central deadbolt for both weather and security.

Operation is as follows;

Locking

- Close the door and lift the lever upward. This action will project the compression bolt and hooks into their respective keeps.
- Rotate the key one revolution, making the door fully weathered and secured
- Please ensure the handle is lifted at all times of closing to prevent bowing of the door, even when not deadlocking

Unlocking


- Insert key in the cylinder and rotate one revolution to retract deadbolt
- Push lever down to fully retract the compression hooks and bolts, the latch will automatically detract when lever is depressed
- This procedure is the same for internal and external operation on lever/lever handles



Split Spindle Lever/Pad Operation

To Lock

Lift the lever to engage the hook bolts, then turn the key to deadlock the door.



To Unlock

Turn the key to unlock the mechanism, then push down on the lever to release the hook locks.



To Unlock the door from the inside please follow same operation as for a lever/lever handle

- To unlock from the outside of the property
- Insert the key into the cylinder and rotate to unlock the gearing
- Depress the lever to withdraw the compression hooks and bolts, this will not withdraw the latch at this point
- Simply turn the key again in the same



Heritage Cylinder Pull & Contemporary Lock Operation

When upgrading to the Contemporary or Heritage lock option, your Entrance Composite Door will be supplied with the new Winkhaus AV4 multipoint lock, the cylinder will operate your door without the need of a handle. Key position at hip height with the contemporary lock and key at shoulder height for Heritage lock

Operation is as follows;

Locking

- Simply close your door! Providing your AV4 is not in the Daylatch position, your door will automatically drop the security hooks when the door is closed behind you. Just pull the door closed with your cylinder pull, pull handle or centre door knob
- To deadlock the door, turn the key one rotation
- See separate Daylatch Feature guide



Unlocking

- Insert key in the cylinder and rotate one revolution. Thanks to the advance technology of the new Winkhaus AV4, the operation tolerances allow you to open your door with ease with just one turn



Contact Us

Tel: 0115 982 7744

Email: enquiries@entrancecds.com

Website: www.entranceway.co.uk

